


Title: Code Handset to Receiver GTX U1




The receiver features 4 separate channels which allows four separate handsets (transmitters) to operate

1. Remove Cover
  - Open Control box by removing screw and carefully remove by tilting cover from bottom



2. Locate receiver board
  - Receiver board is located in the upper left region of the main circuit board
  - The receiver is identified by the brown antenna wire attached



3. Press Learn Button
  - Red LED #1 will illuminate representing channel 1.
  - To select an alternate channel press Learn button until desired LED is illuminated (ie: press twice for channel 2; press four times for channel 4).



4. Press the button on the handset
  - All four LED's on receiver will flash to confirm that the handset has been successfully programmed.
  - Carefully replace cover and affix with screw.

Note: Additional remotes must be programmed to separate channels